



**Fender**®

**MADE IN U.S.A.**

**BANDMASTER REVERB  
SUPER REVERB • PRO REVERB  
AMPLIFIERS**

**OWNER'S  
MANUAL**

MANUAL NO. 013918 (Rev. C)

**WARNING**  
**TO REDUCE THE RISK OF FIRE**  
**OR SHOCK HAZARD, DO NOT**  
**EXPOSE THIS APPLIANCE TO**  
**RAIN OR MOISTURE**

FENDER SPECIAL DESIGN ELECTRONIC TUBES  
PROVIDE OPTIMUM PERFORMANCE IN THIS  
AMPLIFIER. FOR BEST RESULTS, REPLACE WITH  
FENDER ORIGINAL EQUIPMENT TUBES ONLY

MATERIALS AND SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.

---

## **IMPORTANT**

TO REDUCE POSSIBLE PERCEPTIBLE LEAKAGE CURRENT THIS EQUIPMENT IS PROVIDED WITH A GROUNDING TYPE POWER SUPPLY CORD. CONNECT EQUIPMENT TO A GROUNDED RECEPTACLE.

Operation from an ungrounded (2 pronged) A.C. receptacle requires a 3 to 2 contact grounding type A.C. adapter. Be sure to connect the adapter's grounding lead to a good earth ground. DO NOT ALTER THE A.C. PLUG.

Reversing the A.C. adapter in a two conductor A.C. receptacle or changing the GROUND SWITCH position (when provided) may reduce the A.C. power line hum and noise levels. Unless an advantage is apparent, ALWAYS SET THE GROUND SWITCH TO "OFF".


# Fender®

## PRO REVERB SUPER REVERB BANDMASTER REVERB AMPLIFIERS

Copyright © 1982 CBS Musical Instruments  
A Division of CBS Inc.

70 WATTS RMS AND 154 WATTS PEAK MUSIC POWER

Your selection of a Fender amplifier will be rewarded with years of quality music in a wide range of controlled sounds. This manual is designed to familiarize you with the equipment and acquaint you with its many fine features. Read it carefully so that you will benefit from all of the features as soon as you start using the amplifier.



# FRONT PANEL FUNCTIONS

## NORMAL CHANNEL

### INPUT JACKS

Jack No. 1 for use when one instrument is used. Jack No. 2 for use with second instrument or equipment with high output level.

### BRIGHT SWITCH

Adds brilliance to all notes, especially higher frequency notes.

### VOLUME CONTROL

Volume setting from zero to full power output.

### TONE CONTROLS

**Treble Control**—Regulates amount of high frequency response. Complemented by bright switch.

**Middle Control**—Adds a rich tone and accents middle register.

**Bass Control**—Regulates amount of bass response.

## VIBRATO CHANNEL

### INPUT JACKS

Jack No. 1 for use when one instrument is used. Jack No. 2 for use with second instrument or equipment with high output level.

### BRIGHT SWITCH

Adds brilliance to all notes, especially higher frequency notes.

### VOLUME CONTROL

Volume setting from zero to full power output.

### TONE CONTROLS

**Treble Control**—Regulates amount of high frequency response. Complemented by bright switch.

**Middle Control**—Adds a rich tone and accents middle register.

**Bass Control**—Regulates amount of bass response.

### REVERB CONTROL

**Reverb Control**—Selects the amount of reverbation.

### VIBRATO CONTROLS

**Speed**—Regulates the rapidity of the vibrato effect—variable from slow to extremely fast setting.

**Intensity Control**—Increases or decreases the vibrato effect.

## MASTER VOLUME CONTROL

### DISTORTION SWITCH

The Master Volume Control is equipped with a push-pull distortion switch.

### CLEANEST SOUND

To get the cleanest possible sound, push the Master Volume Control knob in and turn it to "10." Adjust the **VIBRATO** channel volume to the desired sound level.

### DISTORTION CONTROL

To get a distortion effect, turn the **VIBRATO** channel volume to "10." Adjust the Master Volume Control to the desired sound level. The amount of distortion is variable: increasing the **VIBRATO** channel volume while decreasing the Master Volume adds distortion; decreasing the **VIBRATO** channel volume while increasing the Master Volume makes the sound "cleaner." Make sure that the guitar is plugged into input jack number 1.


### MAXIMUM DISTORTION

To get the most distortion, turn the **VIBRATO** channel volume control to "10." Pull the Master Volume Control out and adjust it to the desired sound level.

**NOTE:** It is important to have the volume and tone controls of the guitar turned to their maximum to get the most distortion from the amplifier.

**Jeweled Pilot Light**—Indicates when amplifier is turned on.

# REAR PANEL



# REAR PANEL FUNCTIONS

## A.C. ACCESSORY OUTLET

(120 V AC, 60 Hz) (Load limit 200 Watts) This socket is provided as a convenience outlet for any A.C. accessory.

## GROUND SWITCH

Gives player control of polarity. Positions "A" and "B" ground to each side of the line respectively. The "OFF" position disconnects all but the third line chassis ground. Try each position to find minimum hum condition.

## FUSE

2½ Amp 125 Volts Slo-Blo

**CAUTION:** Disconnect amplifier A.C. plug from outlet before changing fuse.

Remove fuse by pressing in and unscrewing cap counter-clockwise. Replace only with Littlefuse No. 31302.5 or Bussman fuse No. MDL 2.5.

## ON / OFF SWITCH

Turns amplifier on and off.

## STANDBY SWITCH

Allows tube filaments to remain heated during standby periods. Amplification is instantly available without warm-up time. No danger of unwanted sound when in quiet periods.

## SPEAKER JACK

Connects speakers to amplifier.

## EXTENSION SPEAKER JACK

Provides a connection to an extension speaker enclosure.

## OUTPUT LINE/RECORDING JACK

Permits direct connection to recorders, P.A. systems or amplifiers, with input impedances of 200 ohms or more.

## OUTPUT TUBES MATCHING

This control makes it unnecessary to use matched power output tubes for optimum performance.

Best balance is obtained by setting the "MASTER VOLUME" to "1" and adjusting for minimum hum level. Ordinarily, no adjustment should be required unless the output tubes are changed.

## VIBRATO AND REVERB JACKS (4)

Plug-in connections to pedal and to reverb unit.

## HUM BALANCE

After the "GROUND SWITCH" has been positioned to minimum hum, the hum balance may be used to further reduce hum. This control should not need adjustment unless tubes or other components are changed.

# CORRECTIVE CHECK LIST

If your amp is set up but does not function, check the following items:

- Is the amp power supply cable plugged into an electrical outlet?
- Is there power at the outlet where the amp is plugged in?
- Is the speaker plugged into the amplifier speaker jack?
- Are all the control knobs turned up above 4?
- Is the volume control on your instrument turned up?
- Is the fuse good?

If, after checking all of the above, the system is still not performing correctly, consult your Fender Service Dealer.

# CARE OF VINYL COVERING

If the vinyl covering and handles require cleaning, use a mild soap and warm water solution, wipe with a damp cloth, and buff dry with a terry cloth. This will restore the original luster.

# REPLACEMENT PARTS

Under the terms of the limited warranty, defective parts will be replaced by your authorized Fender dealer.

Fender Original Equipment tubes are designed and built to provide optimum performance in musical instrument amplifiers.

To maintain best performance and quiet operation, replacement should be made with original equipment tubes.

Fender Musical Instruments furnishes warranty service through authorized Fender dealers.

**NOTE:  
SEE ACCOMPANYING LIMITED WARRANTY  
REGISTRATION SHEET**

Litho U.S.A.

**Fender®**  
MADE IN U.S.A.

**P.O. BOX 4137 • 1300 EAST VALENCIA DRIVE. FULLERTON. CA 92634**