

THUMB REST MOUNTING TEMPLATE (S)*

—— Jazz Bass

----- Precision Bass

MOUNTING INSTRUCTIONS

1. Cut out required pickguard template. Dotted line is Precision Bass and solid line is Jazz Bass.
2. On Jazz Bass remove pickguard from instrument. On the Precision Bass remove the pickguard mounting screws and place a scrap piece of wood between the body and the pickguard. Be sure to pad the guitar with soft cloth between the scrap wood and body so as not to scratch it (this is to make removing the controls from the pickguard unnecessary).
3. Position template on pickguard using perimeter and existing pickguard mounting screw hole (noted) to get proper alignment. Center punch corresponding hole.
4. Drill the center punched hole through with a 5/32 diameter drill bit.
5. Fasten pickguard onto body and use the thumb rest mounting screw holes in the pickguard to locate and center punch body holes.
6. Drill two (2) holes in the body 3/32 diameter by 1 inch deep.
7. Locate thumb rest and screw onto body with No. 5 x 1 oval head sheet metal screws (supplied).

Existing Pickguard Mounting Screw Holes:

○ Precision Bass

● Jazz Bass

* Suggested thumb rest location is noted.

Actual placement is at owner's discretion.