


STD STR HSS + TOP iOS® (014-4730-XXX / 014-4732-XXX)

PARTS LAYOUT



STD STR HSS + TOP iOS ® (014-4730-XXX / 014-4732-XXX)


PARTS LIST

REF #	DESCRIPTION	PART NUMBER
1	BODY STD STRAT + TOP iOS ACB B&P	7704166531
	BODY STD STRAT + TOP iOS TBS B&P	7704165552
2	NECK STD STRAT MN PAINT 2CT	0077946000
	NECK STD STRAT RW PAINT 2CT	0077945000
3	KEY GTR DUAL PIN MNT	0990820100
4	WASHER KEY	0053106049
5	BUSHING KEYS	0058820049
6	STRING GUIDE NICKEL	0994910000
7	SCRW SMAB 3x3/8 RHP NI	0011357049
8	PICKGUARD STRAT 1HB P/B/P	0090878000
9	SCRW SMAB 4x1/2 OHP NI	0015578049
10	SWITCH 5 WAY LEVER W/METAL	0991367000
11	KNOB PICKUP SWITCH PARCHMENT	0056253049
12	SCREW-MA 6-32X5/8 RH ZARTAN	0994925000
13	KNOB STRAT VOLUME PARCH	0056254049
14	KNOB STRAT TONE PARCH	0056255049
15	CONTROL 250K 10% TPR SPLIT	0990830000
16	CONTROL B25K 10% TAPER	7702473000
17	NUT HEX 3/8-32x3/32 TK NI	0016352049
18	WSHR LCK INTL 3/8x.500x.020 NI	0022384049
19	USB GUITAR I/O BOARD ASSY	7703232000
20	JACKPLATE, I/O PCB HOLDER, USB GUITAR	7702480000
21	JACK PHONE 1/4 - OUTPUT	0047329049
22	NUT HEX 3/8-32x3/32 TK NI	0016352049




STD STR HSS + TOP iOS® (014-4730-XXX / 014-4732-XXX)

WIRING DIAGRAM



STD STR HSS + TOP iOS® (014-4730-XXX / 014-4732-XXX)

SWITCH & CONTROL FUNCTION



5 WAY SWITCH POSITION					
5	4	3	2	1	SWITCH POSITION
					← NECK PICKUP
					← MID. PICKUP
					← BRIDGE PICKUP
	PICKUP IS ON		INDICATES POSITION OF 5 WAY SWITCH		
	PICKUP IS OFF				

NOTE : WHEN GUITAR IS CONNECTED TO FISHMAN SOFTWARE BY USB, VOLUMES AND TONE ARE FUNCTIONALS, (MASTER VOLUME, MASTER TONE, HEADPHONE VOLUME AND SELECTOR SWITCH)

