

Fender

Bassman 30
OWNERS MANUAL

IMPORTANT

To reduce the possibility of AC current leakage, this amplifier is provided with a grounding power cord. Be sure to connect it to a grounded receptacle.

Operation from a 2-pronged undergrounded receptacle requires a 3-to-2 grounding adapter. The adapter's grounding lead must be connect to a good earth ground. FENDER's specially designed electronic parts provide optimum performance in this amplifier. For best results, replace with FENDER original equipment parts only.

Congratulations! The selection of a FENDER amplifier will reward you with years of musical satisfaction and place a world of new sounds at your fingertips. FENDER amplifiers combine control, power and reliability in one compact package. This manual will explain the many features and applications available on your new musical tool. Read the manual carefully to gain the maximum benefit from all of the product's features before using it.

The built-in quality of a FENDER amplifier is the result of over three decades of combined research and development between our engineers and musicians.

That is why we say, proudly...FENDER the sound that creates legends!

WARNING: To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.


フェンダーアンプは最高の条件でご使用頂くために専用のパーツが使われています。フェンダーオリジナルパーツ以外の物を使うのは故障の原因となりますのでご注意ください。

フェンダーアンプリファイアーを選んだ貴方は長い年月に渡る音楽的な満足と指先一つで作り出される新しい音楽の世界を約束されます。フェンダーアンプはその小さなパッケージに信頼性の高いコントロールとパワーを秘めています。このマニュアルはいろいろな性能と使い方を紹介したものです。まず使う前によく読んで、全ての特徴を最大限に引き出してください。

フェンダーのビルトインタイプハイクオリティーアンプは30年以上に渡るエンジニアとミュージシャンが協力して行なった研究、開発によって生み出されました。それ故、私たちは誇りをもってこう呼びます……フェンダー、伝説を創造するサウンド。

注意：火災や故障の原因となりますので、雨の中や湿気の高い所での使用はお避け下さい。

FRONT PANEL FEATURES



- Ⓐ INPUT 1—Connection for instrument.
- Ⓑ INPUT 2—Connection for instrument. If only INPUT 2 is used the sensitivity is less than that of INPUT 1.
- Ⓒ VOLUME—Volume from zero to full power for both inputs.
- Ⓓ LIMITER—LED that indicates that the limiter is engaged to prevent distortion (clipping) in the power amplifier section.
- Ⓔ MASTER—Controls overall volume. Special equalization circuits are used to automatically provide a full bass sound at low volume levels. For a “clean” sound, set MASTER at 10 and bring VOLUME up to desired level. For a distorted sound, set VOLUME at 10 and bring MASTER to desired level.
- Ⓛ TREBLE—Provides desired amount of high frequency response or brilliance for both inputs.
- Ⓜ MIDDLE—Provides cut and boost of the mid-range frequencies for both inputs.
- Ⓨ BASS—Provides desired amount of bass response for both inputs.
- Ⓛ LINE OUT—Provides line level output for routing to a mixer or recorder.

- Ⓛ HEADPHONES—Connection for stereo headphones.
- Ⓨ PILOT INDICATOR—Shows that the amp is ON when lit.
- Ⓛ ON/OFF SWITCH—Turns amplifier ON and OFF.
- Ⓐ INPUT 1—楽器を接続します。
- Ⓑ INPUT 2—楽器を接続します。もしINPUT 2のみを使用した場合、アンプの感度はINPUT 1より低くなります。
- Ⓒ VOLUME—両方のインプットの音量を調整します。
- Ⓓ LIMITER—LEDが点灯している時はスピーカーのダメージを防ぐためにリミッターが作動している事を示しています。
- Ⓔ MASTER—両方を調整します。ヴォリュームを低くした場合でも自動的に完全なベースサウンドが得られるような特別なイコライザー回路が組み込まれています。クリーンなサウンドにするには、マスターを10にセットしヴォリュームを調整します。ディストーションサウンドにするにはヴォリュームを10にしてマスターを調整します。
- Ⓛ TREBLE—両方のインプットのハイフリケンシーを調整します。
- Ⓜ MIDDLE—両方のインプットのミドルフリケンシーを調整します。
- Ⓨ BASS—両方のインプットのベースフリケンシーを調整します。
- Ⓛ LINE OUT—ミキサーやレコーダーに接続するためのラインレベルアウトブット端子です。
- Ⓛ HEADPHONES—ステレオヘッドフォン等の接続端子です。
- Ⓨ PILOT INDICATOR—電源を入れた時点灯します。
- Ⓛ ON/OFF SWITCH—ONにすると電源が入り動作可能な状態になります。

LIMITED WARRANTY

Under the terms of the limited warranty, defective parts will be replaced by your authorized Fender Dealer. Fender Musical Instruments furnishes warranty service through authorized Fender Dealers.

If your amp is set up but does not function, check the following items:

- Is the amp power cord properly plugged into an electrical outlet ?
- Is there power at the outlet ?
- Is the speaker properly connected to the amplifier ?
- Are all control knobs turned up above 4 ?
- Is the volume control on your instrument turned up ?
- Is your instrument properly plugged into the amplifier ?

The exclusive Fender vinyl covering on your cabinet has been especially designed for years of lasting beauty. A very light soapy solution on a sponge may be used to remove dirt and residue that may accumulate in the grain. Be careful not to let any liquid come into contact with operating surfaces. Do NOT have amplifier plugged into power outlet when cleaning.

This limited warranty against defects in material and workmanship begins at the date of original retail purchase and lasts for one (1) year from that date. It applies to all components and is limited to the original retail purchaser. You may prove date of purchase by completing and mailing the registration card to Fender Musical Instruments, or retaining a copy of your sales invoice.

Transportation charges are not included in this warranty. If any component of the product is found to be defective, we will furnish a replacement without charge if it is returned to an authorized Fender Dealer, an authorized service technician or, the authorized Fender Service Center at the address provided below. Any damage or defect resulting from unauthorized parts or service is excluded. Any service performed by other than an authorized Fender Dealer, authorized service technician or, the authorized Fender Service Center is not reimbursable under this warranty.

The warranty is void if the serial number is defaced or removed, or the product has been visibly damaged by alteration, misuse, accident or neglect. THE COMPANY

ASSUMES NO LIABILITY FOR PROPERTY DAMAGE WHICH MAY RESULT FROM THE FAILURE OF THIS PRODUCT. Any warranties of MERCHANTABILITY or FITNESS implied by law are limited to the duration of this express limited warranty.

Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

If the Owner's Manual cannot supply the information needed, please contact:

Customer Service Department
Fender Musical Instruments
1130 Columbia Street
Brea, California 92621

WARRANTOR:
FENDER MUSICAL INSTRUMENTS
1130 Columbia Street
Brea, California 92621

Limited Warranty applicable to U.S.A. only. Outside of U.S.A., please consult your local distributor.

製品に関するご質問、故障等につきましてはご購入店またはフェンダー・ジャパンまでお申し出ください。

〒101 東京都千代田区神田鍛冶町3-4-2
フェンダー・ジャパン株式会社 ☎(254)3670代