

BASSMAN 70 AMPLIFIER

OWNER'S MANUAL


MANUAL NO 014236 (Rev. B)



Your selection of a Fender Bass amplifier will be rewarded with years of quality music in a wide range of controlled sounds. This manual is designed to familiarize you with the equipment and acquaint you with its many fine features. Read it carefully so that you will benefit from all of the features as soon as you start using the amplifier.

Copyright (c) 1980 CBS Musical Instrument: A Division of CBS Inc.

70 WATTS RMS AND 154 WATTS PEAK MUSIC POWER



PROMIT PANEL FUNCTIONS

B 3S INSTRUMENT

IMPO. GACKS

Jack No. 1 for use when one instrument is used. Jack No. 2 for use with second instrument or equipment with high output level.

od. ndf

Provides deeper tone (more fundamental, less harmonics).

VOLC. A. CONTROL

Volume setting from zero to full power output.

TOIL ONTROLS

Treble Control — Provides additional high frequencies as required.

Bass Control — Regulates the amount of bass response.

NORMAL CHANNEL

INPUT JACKS

Jack No. 1 for use when one instrument is used. Jack No. 2 for use with second instrument or equipment with high output level.

BRIGHT SWITCH

Adds brilliance to all notes, especially higher frequency notes.

JOLUME CONTROL

Volume setting from zero to full power output.

TONE CONTROL

Treble Control — Provides additional high frequencies as required. Complemented by bright switch.

Bass Control — Regulates the amount of bass response.


MASTER VOLUME CONTROL

- The Master Volume Control simultaneously controls the output of all channels of the amplifier.
- The Master Volume Control when set at 10, provides the maximum "pure sound".
- When the channel volume is set at 10, and the Master Volume Control is adjusted to the desired sound level, maximum distortion is achieved. The degree of distortion can be varied by adjusting the mixture of the Master Volume Control with the Channel Volume Control.
- Experiment for desired sounds by setting the Master Volume Control to lower numbers and the channel volume to higher numbers.

JEWELED Prose TLIGHT

Indicates when amplifier is turned on.

. EAR PANEL



HE R PANEL FU ICTIONS

. C. Ac. LSSORY OUTLET (120 V AC, 60 Hz) (Load limit 200 Watts) This socket is provided as a convenience outlet for any A.C.

JOHN SWITCH

accessory.

Gives player control of polarity. Positions "A" and "B" ground to each side of the line respectively. The "OFF" position disconnects all but the third line chassis ground. Try each position to find minimum hum condition.

USE

2½ Amp 125 Volts Slo-Blo
CAU: 11: Disconnect amplifier
A.C. plug from outlet before changing fuse.

Remove fuse by pressing in and unscrewing cap counter-clockwise. Replace only with Littlefuse No. 31302.5 or Bussman fuse No. MDL 2½.

Turns amplifier on and off.

HAIR. SWITCH

Allows tube filaments to remain neated during standby periods. Amplification is instantly available without warm-up time. No danger of unwanted sound when in quiet periods.

'EAKEH JACK Connects speakers to amplifier.

TENSION SPEAKER JACK
Provides a connection to an extension speaker enclosure.

OFPUT I INE/RECORDING JACK Permits direct connection to recorders, P.A. systems or amplifiers, with input impedances of 200 ohms or more.

JTPUT TUBES MATCHING

This control makes it unnecessary to use matched power output tubes for optimum performance.

Best balance is obtained by setting the "MASTER VOLUME" to "1" and adjusting for minimum hum level. Ordinarily, no adjustment should be required unless the output tubes are changed.

JIM BALANCE

After the "GROUND SWITCH" has been positioned to minimum hum, the hum balance may be used to further reduce hum. This control should not need adjustment unless tubes or other components are changed.

CORRECTIVE CHECK LIST

If your amp is set up but does not function, check the following items:

- Is the amp power supply cable plugged into an electrical outlet?
- Is there power at the outlet where the amp is plugged in?
- Is the speaker plugged into the amplifier speaker jack?
- Are all the control knobs turned up above 4?
- Is the volume control on your instrument turned up?
- Is the fuse good?

If, after checking all of the above, the system is still not performing correctly, consult your Fender Service Dealer.

CARE OF VINYL GOVERING

If the vinyl covering and handles require cleaning, use a mild soap and warm water solution, wipe with a damp cloth, and buff dry with a terry cloth. This will restore the original luster.

REPLACEMENT PARTS


Under the terms of the limited warranty, defective parts will be replaced by your authorized Fender dealer.

Fender Original Equipment tubes are designed and built to provide optimum performance in musical instrument amplifiers.

To maintain best performance and quiet operation, replacement should be made with original equipment tubes.

Fender Musical Instruments furnishes warranty service through authorized Fender dealers.

AGC: SSORIES



Waterproof, tear and abrasion-resistant amplifier covers are available for every Fender amp. They prevent surface damage to the amplifier and keep out dust. Lined with soft flannel.



FUZZ/WAH/VOLUME PEDAL
Up and down foot control for the Fuzz, Wah
and Volume. Separate foot switches for the
Fuzz and Wah. Fingertip pre-setting of balance
and blend of the Fuzz and Wah.

FENDER BASSES YOU'LL WANT TO TRY "Fender basses are engineered to perfectly match the electronic circuitry of your new Fender Amplifier."



JAZZ 1.355

The "thin neck" bass with two pickups for full string tone

- "Slim neck" design lets any guitarist play bass with ease
- Two volume/blend controls for absolute pickup balance



RECISION BASS

Split pickup design for even string response

Wide contoured neck to facilitate advanced playing style

Wide range volume and tone controls



FRETLESS PRECISION BASS

- Gives the "feel" and versatility of an upright string bass
- Wide contoured neck for advanced playing style
- Split pickup for balanced sound throughout entire scale



MUSTANG BASS

- Wide-range split pickup for maximum string response and balanced tone throughout the entire scale
- Four individually adjustable bridge sections for perfect intonation and custom playing action
- Four cushion-type string mutes for true string bass sound