



Fender®

MADE IN U.S.A.

**CHAMP and VIBRO CHAMP
AMPLIFIERS**

**OWNER'S
MANUAL**

MANUAL NO. 010356 (Rev. F)

Fender®

**CHAMP
VIBRO CHAMP
AMPLIFIERS**

Your selection of a Fender amplifier will be rewarded with years of quality music in a wide range of controlled sounds. This manual is designed to familiarize you with the equipment and acquaint you with its many fine features. Read it carefully so that you will benefit from all of the features as soon as you start using the amplifier.

Copyright © 1980 CBS Musical Instruments
A Division of CBS Inc.

6 WATTS RMS AND 12 WATTS PEAK MUSIC POWER

WARNING
TO REDUCE THE RISK OF FIRE
OR SHOCK HAZARD, DO NOT
EXPOSE THIS APPLIANCE TO
RAIN OR MOISTURE

FENDER SPECIAL DESIGN ELECTRONIC TUBES PROVIDE OPTIMUM PERFORMANCE IN THIS AMPLIFIER. FOR BEST RESULTS, REPLACE WITH FENDER ORIGINAL EQUIPMENT TUBES ONLY


SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

IMPORTANT

TO REDUCE POSSIBLE PERCEPTIBLE LEAKAGE CURRENT THIS EQUIPMENT IS PROVIDED WITH A GROUNDING TYPE POWER SUPPLY CORD. CONNECT EQUIPMENT TO A GROUNDED RECEPTACLE.

Operation from an ungrounded (2 pronged) A.C. receptacle requires a 3 to 2 contact grounding type adapter. Be sure to connect the adapter's grounding lead to a good earth ground. DO NOT ALTER THE A.C. PLUG.

Reversing the A.C. adapter in a two conductor A.C. receptacle may reduce the A.C. power line hum and noise levels.



FRONT PANEL

INTENSITY (VIBRO CHAMP ONLY)
CONTROL

SPEED CONTROL (VIBRO CHAMP ONLY)

FRONT PANEL FUNCTIONS

INPUT JACKS

Jack No. 1 for use when one instrument is used. Jack No. 2 for use with second instrument or equipment with high output level.

VOLUME CONTROL

Volume setting from zero to full power output.

TONE CONTROLS

Treble Control — Provides additional high frequencies as required.

Bass Control — Regulates desired amount of bass response.


SPEED, VIBRATO CONTROL (Vibro Champ only)
Regulates the rapidity of the vibrato effect—variable from slow to extremely fast setting.

INTENSITY, VIBRATO CONTROL (Vibro Champ only)
Increases or decreases the vibrato effect.

JEWELLED PILOT LIGHT

Indicates when amplifier is turned on.

REAR PANEL



REAR PANEL FUNCTIONS

FUSE

Caution — To reduce the risk of fire, replace only with same type 1 amp. 125 volt Slo Blo fuse.

SPEAKER JACK

Connects speaker to amplifier.

CORRECTIVE CHECK LIST

If your amp is set up but does not function, check the following items:

- Is the amp power supply cable plugged into the wall?
- Is there power at the wall outlet where the amp is plugged in?
- Is the speaker plugged into the amplifier speaker jack?
- Are the tone control knobs turned up above 4?
- Is the volume control on your instrument turned up?
- Is the fuse good?

If, after checking all of the above, the system is still not performing correctly, consult your Fender Service Dealer.

CARE OF VINYL COVERING

If the vinyl covering and handles require cleaning, use a mild soap and warm water solution, wipe with a damp cloth, and buff dry with a terry cloth. This will restore the original luster.

REPLACEMENT PARTS

Under the terms of the limited warranty, defective parts will be replaced by your authorized Fender dealer.

Fender Original Equipment tubes and parts are designed and built to provide optimum performance in musical instrument amplifiers.

To maintain best performance and quiet operation, replacement should be made with original equipment tubes from your authorized Fender Dealer.

Fender Musical Instruments furnishes warranty service through authorized Fender dealers.

**NOTE:
SEE ACCOMPANYING LIMITED WARRANTY
REGISTRATION SHEET**

Litho U.S.A.

Fender®
MADE IN U.S.A.

P.O. BOX 4137 • 1300 EAST VALENCIA DRIVE, FULLERTON, CA 92634