




# ERIC CLAPTON STRATOCASTER UPGRADE 0117602



PICKGUARD ASSEMBLY



BRIDGE ASSEMBLY

























# ERIC CLAPTON STRATOCASTER UPGRADE 0117602

REF.#	P/N	DESCRIPTION	REF.#	P/N	DESCRIPTION
1	0029685000	Neck, Clapton Stratocaster, M/N		0019273000	Intonation Spring, 5&6
2	0019309000	Tuning Key, (1) Set		0019281000	Intonation Spring, 1-4
	0011357000	Mounting Screw	27	0032782000	Height Adjustment Screw, 1&6
	0019312000	Bushing		0016071000	Height Adjustment Screw, 2-5
3	0083675000	Bone Nut		0018531000	Height Adjusting Wrench
4	0010389000	String Retainer	28	0012180000	Spring, Tremolo
	0011358000	Mounting Screw	29	0019649000	Back Plate, Tremolo, White
	0020423000	Spacer		0015578000	Mounting Screw
5	0020810000	Truss Rod Adjustment Nut			
	0023811000	Truss Rod Adjusting Wrench			
6	0028451xxx	Body, Clapton Strat, Solid Paint			
7	0054038000	Neck Mounting Plate (Tilt)			
	0015636000	Mounting Screw			
	0031571000	Tilt Adjustment Screw			
	0023811000	Tilt Adjusting Wrench			
8	0012344000	Strap Button			
	0016188000	Mounting Screw			
9	0019490000	Pickguard, Vintage Strat, White			
	0015578000	Mounting Screw			
10	0058018000	Pickup, Neck/Middle (2), Noise Free			
11	0058019000	Pickup, Bridge, Noise Free			
	0015776000	Mounting Screw			
	0036878000	Tubing, Latex Cut			
12	0021682000	Control, 50k, Audio			
	0016352000	Mounting Hex Nut			
	0022384000	Lock Washer, Intl			
13	0021686000	Control, Mid Tone, 250K, 1 Meg Dual			
	0016352000	Mounting Hex Nut			
	0022384000	Lock Washer, Intl			
14	0028531000	Control, Mid Boost, 250K, Taper			
	0016352000	Mounting Hex Nut			
	0022384000	Lock Washer, Intl			
15	0056149000	Knob, Volume, Aged White			
16	0056148000	Knob, Tone, Aged White, (2)			
17	0053291000	Switch, Lever, 5 Position			
	0015776000	Mounting Screw			
	0019554000	Knob, Aged White			
18	0024832000	Capacitor, .022uf			
19	0024996001	Resistor, 82K			
20	0012869000	Solder Lug			
	0015116000	Mounting Screw			
21	0039432000	Output Jack			
	0016352000	Mounting Hex Nut			
	0016436000	Lock Washer, Intl			
22	0010280090	Jack Ferrule			
	0015578000	Mounting Screw			
23	0019642000	Bridge Assembly, Vintage Strat			
	0016170000	Mounting Screw			
	0019473000	Bridge Block			
	0019656000	Mounting Screw			
	0010272100	Claw, Tremolo			
	0015636000	Mounting Screw			
	0031643000	Spring, Claw			
	0019652040	Arm, Tremolo			
	0019463000	Knob, Tremolo			
24	0019470000	Bridge Plate			
25	0019280000	Bridge Section, (6)			
26	0015693000	Intonation Screw, (6)			

Body Part Number	
0028451505	Olympic White
0028451506	Black
0028451543	Pewter
0028451558	Torino Red
0028451571	Candy Green

SWITCH & CONTROL FUNCTION

5 WAY SWITCH POSITION					
					← 5 WAY SWITCH POSITION
					← NECK PICKUP
					← MIDDLE PICKUP
					← BRIDGE PICKUP
	← PICKUP IS ON				← PICKUP IS OFF

