

# 60's CLASSIC PLAYER STRATOCASTER®, 014-1100

| REF.# | P/N        | DESCRIPTION                               |
|-------|------------|---|
| 1     | 0072276000 | Neck, 60's Classics Player Strat® Mex, RW |
| 2     | 0047912000 | Tuning Key, Vintage (Set)                 |
|       | 0053020000 | Bushing, Key Vintage                      |
|       | 0011357000 | Mounting Screw                            |
| 3     | 0010389000 | String Guide                              |
|       | 0020423000 | Spacer                                    |
|       | 0011358000 | Mounting Screw                            |
| 4     | 0083675000 | Bone Nut                                  |
| 5     | See Chart  | Body, 60's Classic Player Strat® Mex      |
| 6     | 0072246000 | Neck Mounting Plate, Custom Shop Designed |
|       | 0015636000 | Mounting Screw                            |
| 7     | 0012344000 | Strap Button                              |
|       | 0015610000 | Mounting Screw                            |
| 8     | 0039492002 | Pickguard, MNTGR 62 Vintage Strat         |
|       | 0015578000 | Mounting Screw                            |
| 9     | 0073056000 | Pickup, Custom Shop '69, Neck             |
|       | 0015776000 | Mounting Screw                            |
|       | 0039409000 | Mounting Tube                             |
| 10    | 0073056000 | Pickup, Custom Shop '69, Middle           |
|       | 0015776000 | Mounting Screw                            |
|       | 0039409000 | Mounting Tube                             |
| 11    | 0073056000 | Pickup, Custom Shop '69, Bridge           |
|       | 0015776000 | Mounting Screw                            |
|       | 0039409000 | Mounting Tube                             |
| 12    | 0013446000 | Control 250K, Volume                      |
|       | 0016352000 | Mounting Nut                              |
|       | 0016436000 | Lock Washer                               |
| 13    | 0013446000 | Control 250K, Tone (T1)                   |
|       | 0021022000 | Capacitor, PF RDL .1µF                    |
|       | 0016352000 | Mounting Nut                              |
|       | 0016436000 | Lock Washer                               |
| 14    | 0013446000 | Control 250K, Tone (T2)                   |
|       | 0016352000 | Mounting Nut                              |
|       | 0016436000 | Lock Washer                               |
| 15    | 0053291000 | Switch, 5 Way Grigsby w/ Metal Roller     |
|       | 0015776000 | Mounting Screw                            |
| 16    | 0056145000 | Knob, Volume Strat, Aged White            |
| 17    | 0056144000 | Knob, Tone Strat, Aged White              |
| 18    | 0053765000 | Knob, Pickup Sel Switch, Aged White       |
| 19    | 0040824002 | Back Plate, Vint Strat, White             |
|       | 0015578000 | Plate Mounting Screw                      |
|       | 0050918000 | Claw Spring                               |
|       | 0031643000 | Spring Tremolo                            |
|       | 0015636000 | Spring Tremolo Mounting Screw             |
| 20    | 0047329000 | Output Jack                               |
|       | 0016436000 | Lock Washer                               |
|       | 0016352000 | Mounting Hex Nut                          |
|       | 0010280090 | Jack Ferrule                              |
|       | 0015578000 | Mounting Screw                            |
| 21    | 0072253000 | Bridge Assy, 2 PT. Trem, Ping             |
|       | 0028958000 | Insert                                    |
|       | 0028957000 | Mounting Screw                            |

### BODY CHART

| P/N        | COLOR            |
|------------|------------------|
| 0072279500 | 3 COLOR SUNBURST |
| 0072277500 | SONIC BLUE       |



# 60's CLASSIC PLAYER STRATOCASTER®, 014-1100

## SWITCH & CONTROL FUNCTION

| 5 WAY SWITCH POSITION |                 |    |    |    |  |
|-----------------------|-----------------|----|----|----|--|
| 5                     | 4               | 3  | 2  | 1  |  |
| T1                    | T1&T2           | T2 | T2 | NT |  |
|                       |                 |    |    |    | ← NECK PICKUP (A)                      |
|                       |                 |    |    |    | ← MIDDLE PICKUP (B)                    |
|                       |                 |    |    |    | ← BRIDGE PICKUP (C)                    |
|                       | PICKUP IS ON    |    |    |    | <br>INDICATES POSITION OF 5 WAY SWITCH |
|                       | PICKUP IS OFF   |    |    |    |  |
| A                     | PICKUP (NECK)   |    |    |    |  |
| B                     | PICKUP (MIDDLE) |    |    |    |  |
| C                     | PICKUP (BRIDGE) |    |    |    |  |
| NT                    | NO TONE         |    |    |    |  |



